




SHFR Power Supply Failures



+5V	😊
+15V	😊
+24V (DELAYED)	😊
+24V (UNREGULATED)	😊
-15V	😊
+3.3V	😊
+24V (PERMANENT)	😞



MAIN TAKEAWAY

Voltage Rail Faults can create misleading symptoms throughout the system.

Hey there Subscriber,

These following errors involve.....

- **Err 038 — +5V Failure**

Reset, reboot, call service if needed

- **Err 039 — +15V Failure**

Reset, reboot, call service if needed

- **Err 065 — +24 Delayed Failure**

Reset, reboot, call service if needed

- **Err 066 — +24 Unregulated Failure**

Reset, reboot, call service if needed

- **Err 067 — -15V Failure**

Reset, reboot, call service if needed

- **Err 068 — +3.3V Failure**

Reset, reboot, call service if needed

- **Err 069 — +24 Permanent Failure**

Reset, reboot, call service if needed

 **Need full troubleshooting steps?**

See the **SHFR Error Code Operator Guide** for detailed procedures:

Open SHFR Error Code Guide



Have More Questions?

Browse our authorized dealer portal website. This site contains documentation to assist with installation, maintenance, and troubleshooting of Summit supported X-ray equipment.

SUMMITXRAY.COM>

Congratulations to the
Field Service Engineers
who have completed
certifications:

Benjamin Neaves on Nova
OTS/OTC & SHFR Generator

LOCATE US

SUMMIT INDUSTRIES
7555 N CALDWELL AVE
NILES, ILLINOIS 60714

CONTACT US

tscalls@summitindustries.net
customerservice@summitindustries.net
[\(773\)588-2444](tel:(773)588-2444) or [\(773\)353-4000](tel:(773)353-4000)

